

Keys Of Gold

Vintage keyboards sound collection for Kurzweil PC3 serie

		Controlers		Sliders / knobs								
Kurzweil PC3/PC3K		MWheel	Switch	A	B	C	D	E	F	G	H	I
Kurzweil PC3Le		MWheel	Sw1	1	2	6	7	8	10	4	9	5
1	Pure Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
2	"Regulate" Rhds	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
3	Natural Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
4	Fender Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
5	Stereo Suitcase	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
6	Bright Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
7	Hard Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
8	Warm Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
9	Noisy Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
10	Soft Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
11	Tines Rhodes	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
12	Faz Rhodes	Phaser Depth	Compressor	Phaser Speed	Hammer level	Tines Level	Release Noise	Mic Overdrive	EQ Low	EQ Mid	EQ High	Reverb
13	Natural Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
14	Bright Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
15	Chorused Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
16	Hard Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
17	Attack Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
18	OD Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
19	Mellow Wurly	Tremolo Depth	Compressor	Tremolo Speed	Hammer level	Tines Level	Release Noise		EQ Low	EQ Mid	EQ High	Reverb
20	Natural O'Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
21	Piano + Choir	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Choir Level	Alt String Level		High Cut	Reverb Time	Reverb Level
22	Mellow Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
23	Distant Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
24	Saloon Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
25	Trouble Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
26	Compress Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
27	Mad World Piano	Sympathic Tuning	Compressor	Hammer Level	Release Pedal	Sympathic Reso	Detune	Alt String Level	Bottom Cut	High Cut	Reverb Time	Reverb Level
28	Screamin' Clav'	Vibrato	Compressor	BP Width	BP Freq			Drive	EQ Low	EQ Mid	EQ High	Reverb
29	Pure Clavinet	Vibrato	Compressor	Attack Level	Release Level				EQ Low	EQ Mid	EQ High	Reverb
30	Cyclic Clavinet	Vibrato	Compressor	Wah Speed	Wah Depth	Wah Frequency	Wah Width		EQ Low	EQ Mid	EQ High	Reverb
31	Stereo Clavinet	Vibrato	Compressor	Attack Level	Release Level				EQ Low	EQ Mid	EQ High	Reverb
32	Vel Clavinet D6	Vibrato	Compressor	Attack Level	Release Level				EQ Low	EQ Mid	EQ High	Reverb
33	M-Tron Clavinet	Vibrato	Compressor	BP Width	BP Freq	M-Tron Mix			EQ Low	EQ Mid	EQ High	Reverb